
# LG ENVOY




Life's Good
















LGusa.com/envoy









#### OPEN

- 1. Directional Key
  - ∧ Favorites
    ∨ easyedge<sup>SM</sup>
  - > My Menu
  - < Calendar
- 2. Left Soft Key (Messaging)
- 3. Speakerphone Key
- 4. Send Key

- 5. Voicemail Key
- 6. Vibrate Mode/Shift Key
- 7. Microphone
- 8. Lock Key
- 9. Power/End Key 10. Clear & Back/
- Voice Commands Key 11. Right Soft Key (Contact List)

### CLOSED

- 12. Menu/OK Key
- 13. Earpiece
- 14. Headset Jack
- 15. Volume Up/Down Keys
- 16. Micro USB Charging Port
- 17. Camera Key 18. Camera Lens
- 19. External Display

LG Envoy's large keypad makes dialing phone numbers quick and easy.

#### Make a Phone Call

- From standby mode, begin dialing a number or start spelling the name of the desired contact.
- 2. Press the **Send Key** to call the number or highlight the contact you wish to call and press **ok**.

#### From Recent Calls

- 1. From standby mode, press the Send Key.
- 2. Highlight the number you wish to call and press the **Send Key**.





When you need to communicate quickly and privately, use text messaging.

# Send a Message

- From standby mode, press the Left Soft Key for Message.
- 2. Select New Text Message (1).
- 3. Enter the recipient's number or press the **Right Soft Key** for **Options** to access your contact list.
- 4. Scroll down to the **Text field**, enter your message, and then press OK for **Send**.





Customize your phone by changing ringtones and alert sounds!

# Adjust Master Volume

 From standby mode, press up or down on the Volume Keys to bring up the Master Volume screen, and then press up or down on the Volume Keys to adjust the volume.

# Adjust Volume from Settings Menu

- 1. From standby mode, press OK for Menu.
- 2. Select Settings (9) and then choose Sound (1).
- 3. Select Volume & Vibrate (2).
- 4. Select a volume type and adjust accordingly.

# Change Ringtone and Sounds

- 1. From standby mode, press or for Menu.
- 2. Select Settings (9) and then choose Sound (1).
- 3. Press OK for Ringtones (1).
- Select a ringtone type and then choose between default sounds or your own voice memos. Highlight a tone and press the Left Soft Key for Set.
- To adjust alert sounds, select Message Alerts (3) in the Sound Settings menu and follow step 4.





Envoy has plenty of space for your numbers and email addresses. Back up your contacts with My Contacts Backup in case your phone is ever lost or stolen.

#### Add a Contact

- From standby mode, press the Right Soft Key for Contacts.
- 2. Press the Left Soft Key for New.
- 3. Enter the contact's information and then press or for Save

#### **Back Up Contacts**

- 1. From standby mode, press or for Menu.
- 2. Select My Contacts Backup (0).
- 3. Press the Left Soft Key for Next.
- 4. Read the terms and conditions and press the **Left Soft Key** for **Yes**.
- 5. Enter a PIN that's easy for you to remember—you'll need it to manage your account online.
- 6. Press the Left Soft Key for OK twice.
- 7. Press the **Left Soft Key** for **Yes** to back up your contacts.
- 8. Press OK.





Capture life as it happens with Envoy's VGA camera and then send your photos to your friends.

1. From standby mode, press and hold .

2. You may adjust settings such as white balance and brightness. When you're ready, press

From here you may choose to view the photo, send it to a friend, or upload it to your online album.





Browse the web directly from your mobile phone! Check the weather, visit your favorite websites, and enjoy access to the Internet on the go!

- 1. From standby mode, press OK for **Menu**.
- 2. Select Browser (7).
- 3. If prompted, press OK for Yes (1).
- 4. Press the **Right Soft Key** for **Menu** and then select **Go to URL (5)**.
- 5. Enter a web address, scroll down to **Go**, and press ok.
- 6. To exit the browser, press





Personalize your Envoy by changing the wallpaper, banner, and font type.

- 1. From standby mode, press oK for **Menu**.
- 2. Select Settings (9) and then choose Display (2).

# Change Wallpaper

- From the Display Settings menu, select Wallpaper (1).
- 2. Choose from default images or your own photos.
- 3. Highlight an image and press the **Left Soft Key** for **Set**.

### Change Banner

- 1. From the **Display Settings menu**, select **Banner (2)**.
- 2. Scroll to the **Text field**, enter a new banner, and press or for **Save**.

# Change Font Type

- 1. From the Display Settings menu, select Font Settings (7) and then choose Font Type (1).
- 2. Highlight a font type and press OK.





Download ringtones, apps, games, and wallpaper via **easy**edge.

- 1. From standby mode, press ox for Menu.
- 2. Press or for easyedge (5).
- 3. Highlight a category and press ok.
- 4. Follow the prompts to purchase content.





Connect to headsets, computers, and more via *Bluetooth* wireless technology.

- Place the Bluetooth device you wish to pair with in pairing mode.\* From standby mode, press or for Menu.
- 2. Select Settings (9) and then choose Bluetooth (5).
- 3. Select **Paired Devices (1)** and then press the **Left Soft Key** for **Search**.
- 4. If Bluetooth power is off, press ok for Yes (1) to turn it on.
- 5. Select New Search (1).
- 6. Highlight the device you wish to pair\* with and press ok.
- 7. Press OK for Yes (1) to connect to the device.





Note: Bluetooth accessories sold separately.

<sup>\*</sup>Refer to your *Bluetooth* accessory's user guide for information about initiating pairing mode and the passcode if asked (typically "0000").



Bluetooth Stereo Headset (HBS-700)



Bluetooth Headset (HBM-235 - Purple and Black)



Bluetooth Headset with Vehicle Power Charger (HBM-585)



Vehicle Power Charger



Bluetooth Headset with Speakerphone and Solar Charging Cradle (HBM-810)



Bluetooth Headset (HBM-570 – Silver, Dark Blue, Pink. and Purple)

Maximize your phone with these cutting-edge accessories at www.LGusa.com/envoy



All materials in this guide including, without limitation, the design, the text, and any marks are the property of Ebettonics, inc. Copyright © 2011 LG Electronics, inc. ALL RIGHTS RESERVED. LG and the LG logo are registered trademarks of LG Electronics, inc. Envoy "is a trademark of LG Electronics, inc. The Bluetooth" word mark and logos are registered trademarks or HG. Inc. and any use of such marks by LG Electronics MobileComm, U.S.A., Inc. is under license. microSD" is a trademark of SanDisk. easyedge" is a service mark of U.S. Cellulat" Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are soid separately. All features, functionality, and other product specifications are subject to change. Screen shots are simulated and subject to change.

